

TAMS L488 Quick Start for Agilent VEE

1. Use the L488 Quick Start for Microsoft Windows to configure the TAMS L488 and add the interface using Agilent Connection Expert (ACE). Be sure to check "Auto discover instruments connected to this interface" in ACE.
2. In Agilent VEE, select Menu IO / Instrument Manager
3. Click "Find" in the Instrument Manager toolbar
4. Agilent VEE will create a new entry for the GPIB instrument
5. Right click on this entry and select "Create Direct IO Object"
6. Drag the Direct IO Object into the Main window and click to add it to your program
7. Double-click to add transactions to this object.

For example, this Agilent VEE program sends "*IDN?" to the instrument at GPIB address 7 and then reads and displays the response.

